


WIRING DIAGRAM FOR THE BODY CONTROL MODULE (BCM) OF A 1994 PONTIAC VECTRA. THE DIAGRAM SHOWS THE ELECTRICAL CONNECTIONS BETWEEN THE BCM AND THE VEHICLE'S ELECTRICAL SYSTEM, INCLUDING THE IGNITION SWITCH, INSTRUMENT CLUSTER, AND FUEL ENABLE SIGNAL.



IMPORTANT:
 ANY NEW BODY CONTROL MODULE WILL AUTOMATICALLY PROGRAM TO THE RESISTANCE OF THE KEY (OR INTERROGATOR SETTING) BEING USED AT THE FIRST IGNITION "ON" CYCLE. THIS CAN ONLY BE DONE ONCE FOR THE LIFE OF THE MODULE.

